



# Crankk official guide for Beta group:

How to import your Wallet Secret key into your Local Dashboard


This guide is **NOT** applicable for the following gateways:  
**Browan, Cotx X1, Dragino, Match X2, Milesight**

They are light gateways and **do not** have access to the local dashboard.

## 1. Check your gateway's local IP address:

- use free IP scanner such as Advanced IP Scanner
- or check your router's settings

## 2. Paste the IP address into your browser's address bar and add the port number :17080 afterwards




Username: **admin**

Password: **the last 6 letters from your gateway ID**

### 3. Navigate to the **Wallet** section and enter your secret key:

- Please ensure that you copy and paste the **secret key** exactly as it is, without any spaces or other symbols
- Also, please double-check that it is the correct **secret key** and that it does not belong to another gateway.
- Note that your **secret key** is different from your **wallet address/public key**




Hit **Save**.

If you have entered the correct secret key, then you will see your wallet address displayed in the **Wallet** field. Congratulations! You now have access to additional features that relate to the PONP/Consensus activity of your device.

Check **Blockchain** section to explore the new functionality.

If you entered the wrong secret key you have the option to **Reset** it.



If you require assistance, please don't hesitate to contact our support team.